	Task	50 hrs	500 hrs	1000 hrs	1500 hrs	2000 hrs	2500 hrs	3000 hrs	3500 hrs
Overall									
Neutral circuit	Check		х	х	х	Х	х	х	Х
Greasing	Perform		Х	Х	Х	Х	Х	Х	Х
Battery condition	Check			Х	Х	Х	Х	Х	Х
Inner air filter & fresh air filter	Clean		Х		Х		Х		Х
Inner air filter & fresh air filter	Replace			х		Х		х	
Brake pedal	Adjust			Х	х	Х	х	х	х
Parking brake lever	Adjust		х	X	X	X	X	X	X
Parking brake cable	Replace							Х	
Toe-in	Adjust		х	х	х	Х	х	х	х
Air conditioner pipes and hoses	Check		x	X	X	X	X	X	X
Air conditioner drive belt	Check		x	x	x	X	x	x	x
CAB isolation cushion	Check		Α	X	,	X		X	
Engine				X				X	
Engine oil & filter	Replace	x	х	х	х	х	х	х	х
Fan belt	Adjust	X	X	x	x	X	X	X	X
Fuel tank water	Drain	^	X	X	X	X	X	X	X
Pre-fuel filter	Clean		X	X	X	X	X	X	X
Fuel filter	Replace		X	X	X	X	X	X	X
Fuel line	Check		X		X				
Radiator hose and clamp	Check			X	X	X	X X	X	X
Cooling system	Flush		Х	Х	X	X	X	Х	Х
Intake air line	Check		,	.,	.,	X		.,	
Air cleaner primary element and secondary element	Replace		Х	X	Х	X	Х	X	Х
Exhaust manifold	Check			X		X		X	
DEF injector tip	Clean			Х		Х		X	
DEF (AdBlue) line	Check				Х			X	
DEF pump filter	Replace				Х			Х	
Oil separator hose & check valve	Check				Х			Х	
Antifrost heater for oil separator	Check			Х		Х		Х	
Oil separator hose	Check			Х		Х		Х	
DPF differential pressure sensor pipe	Check					Х		Х	
EGR pipe	Check					Х		Х	
Turbocharger						Х		Х	
•	Check		<u> </u>					Х	
Transmission & Hydraulics Transmission fluid	Chango	1	1	ı	ı		ı	ı	
Transmission oil filter	Change		Х	Х		Х		Х	
Hydraulic oil filters (suction & return sides)	Replace Replace	Х	Х	Х		Х		Х	
Oil cooler line	Check		Х	Х	Х	Х	Х	Х	Х
Power steering oil filter			Х	Х	Х	Х	Х	Х	Х
	Replace		Х	Х	Х	Х	Х	Х	Х
Power steering oil line Lift cylinder hose	Check		Х	Х	Х	Х	Х	Х	Х
	Crieck		Х	Х	Х	Х	Х	Х	Х
Axles	Observe	1	ı	ı	I		I	ı	Ī
Wheel bolt torque	Check		Х	Х	Х	Х	Х	Х	Х
Tie-rod dust cover	Check		Х	Х	Х	Х	Х	Х	Х
Differential lock hose	Check		Х	Х	Х	Х	Х	Х	Х
Brake hose	Check		Х	Х	Х	Х	Х	Х	Х
Rear axle case oil	Change	ļ	Х	Х		Х		Х	
Front differential case oil	Change			Х		Х		Х	
Front axle gear case oil	Change	<u> </u>	<u> </u>	Х		Х		Х	
If Equipped	01 :								
Air brake	Check		Х	Х	Х	Х	Х	Х	Х
Front PTO oil	Check		Х						
Front PTO oil	Change			Х	Х	Х	Х	Х	Х
Front suspension hose	Check		х	Х	Х	Х	Х	Х	Х